

ASSEMBLY INSTRUCTIONS

REPLACING THE UMBRELLA CANOPY, ROUND UMBRELLA





ASSEMBLY INSTRUCTIONS

REPLACING THE UMBRELLA CANOPY, ROUND UMBRELLA

- ❶ Unscrew the wooden ball from the top of the umbrella.
- ❷ Using a cordless screwdriver, remove the screws on both ends of every strut.
- ❸ Once you have released the old canopy completely from the frame, lift the frame up and remove the canopy.
- ❹ Spread the new canopy out in front of you (with the outer side facing down) and insert the frame as far as the center as shown in Fig. 3. There is a hole in the middle of the canopy. Insert the wooden ball through this hole from the outside, fit the protective disk for the upper umbrella hub onto the shaft **on the inside** of the canopy and screw the ball onto the umbrella hub. Caution! Do not screw in tightly. It must remain possible to move the canopy easily.
- ❺ If you now fold the canopy back over the frame, it reaches the ends of the struts. Grip the reinforced point of the canopy which lies closest to a strut, pull it about 1 cm beyond the end of the strut and hold it in position as shown.
- ❻ Now pre-drill the two holes for the screws with a 2.5 mm \varnothing wood drill.
- ❼ Place one screw with collar in each hole and tighten with a cordless screwdriver.
- ❽ Proceed in the same way for each strut in turn.
- ❾ Put up the canopy until it is stretched taut. You may have to drill a new hole for the locking pin if the old bore hole no longer fits. To do this, drill a hole horizontally through the umbrella pole using a wood drill, 8.5 mm \varnothing . If you have a countersink to hand, you can use it to deburr the bore hole to improve the appearance.
- ❿ Fold the canopy and screw the wooden ball on the top tight.