**ASSEMBLY INSTRUCTIONS** 

## BALCONY BISTRO TABLE





**Included in delivery:** 1 x table top, 3 x table leg, 1 x guide plate for leg, 6 x rounded head screw, 6 x nut, 12 x washer, 1 x open-end wrench, 1 x hex-wrench 3 mm



**Teak or HPL table top:** Fix the legs to the table top using the rounded head screws/washers and hex-wrench. Tighten the screws but do not tighten the screws fully yet. (It must be possible to move the legs, see (3))



Now attach the three table legs to the guide plate using the washers and nuts. Tighten the nuts with an open-end wrench.

WEISHÄUPL

**Teak or HPL table top:** Now tighten the rounded head screws to fix the legs firmly to the table top.

**ASSEMBLY INSTRUCTIONS** 

## BALCONY BISTRO TABLE





